ALLARM Shale Gas Volunteer Monitoring Workshop





Dickinson

Workshop funded by Colcom Foundation and Consortium for Scientific Assistance to Watersheds (C-SAW)

Contents

ALLARM Background	3
Science of Shale Gas	7
Volunteer Monitoring Protocol	17
Monitoring Locations & Well Permits	33
Safety Considerations	46
Physical Parameters	51
Chemical Parameters	86
Data Management & Quality Control	105

ALLARM Background

Empower communities with scientific tools to monitor, protect, and restore PA streams.





Educate. Engage. Empower.

Who we are

- Project of the environmental studies department (1986)
- 3 full time directors
- 1 science advisor/Dickinson faculty member
- 10 14 students




ALLARM History




Watershed Technical Assistance

Shale Gas


Monitoring Program	Region	Volunteers	Model
Acid Rain	Statewide	Individuals	Contributory
Watershed TA	Southcentral PA	Groups	Co-created
Shale Gas	Marcellus & Utica	Groups & Individuals	Collaborative




Science of Shale Gas




Depth of Marcellus Shale




Depth to Utica Shale



Shale Gas Wells in Region



Unconventional vs. Conventional



Differences in Drilling

Traditional Hydrofracking

• In traditional hydrofracking, typically 20,000 to 80,000 gallons of fluid were used each time a well was hydrofractured.


- Traditional hydrofracking used 700 to 2,800 lbs. of chemical additives
- 1940s

High Volume Hydrofracking (HVHF)


- HVHF uses between 2 and 10 million gallons of fluid (on average 5.6 million), the exact amount depends upon the length of the well bore and the number of fractures created along the lateral extent.
- HVHF uses between 205,000 and 935,000 lbs. of chemical additives, per well many of which are toxic to humans and wildlife.
- Late 1990s

3 Types of Pipelines

- **1. Gathering**: Usually 6-24 inches in diameter. Carry gas at about 715 psi. These pipelines can travel long distances and there is no requirements to mark them or continually make sure they are cleared of vegetation etc. May clear rights-of-way of 30 to 150 feet wide.
- **2. Transmission**: Large steel pipes (usually 24-48" in diameter), carry gas 200-1200psi. These federally regulated pipelines fall under eminent domain so don't need land owner permission. The land is periodically cleared of large vegetation. Permanent structures and trees may never be placed there. Right-of-way widths of up to 200 feet.
- **3. Distribution**: Small pipes (2-24" in diameter) that can be made of steel, cast iron, plastic or copper. Pressure of gas is reduced to less than 200psi. Mercaptan is added to the gas to give it a rotten egg odor at the city gate prior to being sent through distribution lines.




Hydraulic Fracturing (Fracking)



This protocol documents flowback pollution and visual observations in small streams.

Drilling Wastewater

- Frack water
 - Fluid that goes down the well
 - 160+ known hazardous materials
- Flowback water
 - Fluid that comes back out of the well
 - Steel and power companies can't use it because TDS levels are too high
 - Recycled
 - Inject water into ground or caverns/mines
 - Treat at authorized treatment facilities



September 2009

Flowback water

Flowback water: water that returns to surface it consists of frack water plus chemicals released from underground rock formations.

- Quantity: 10-15% of frack water flows back
- Quality:
 - Brine (salty water) including high concentrations of chlorides, sulfates: very high TDS
 - Metals, e.g. barium iron, manganese, arsenic, strontium, lead, cadmium, chromium, aluminum
 - Naturally occurring radioactive materials such as uranium, radium, and radon
 - Bacteria
 - Methane
- Pathway to environment: spills, incomplete treatment, well casing leaks, migration through bedrock, illegal dumping



Volunteer Monitoring Protocol

Survey Type	Parameters	Methodology	Frequency
Chemical	 Conductivity and total dissolved solids Barium and strontium 	LaMottePockeTesterCertified labanalysis	WeeklyTwice a year and to confirm contamination event
Water quantity	• Stage	Stream stage measurement	• Weekly
Physical	 Gas Related Earth Disturbance Spills and Discharges Gas Migration or Leakage Pipelines 	Visual survey	• Weekly



Why Volunteer Monitoring?



Volunteer Monitoring

- Citizens involved in data collection
- US: 1890 2016
- 48 states
- PA Streams: 1980s



National Weather Service

NJ Watershed Watch Network






Citizen Stewards Water Quality Monitoring Program





Volunteer Monitoring

- Feasibility
- Affordability
- Scientifically robust





ALLARMwater.org

Red Flag Protocol: What Will You Monitor?

1. Flowback Monitoring:

Chemical Parameters

Indicator chemicals
Conductivity & TDS
Signature Chemicals
Barium
Strontium



Stage Monitoring
Relationship to
conductivity



2. Physical Impacts

Visual Observations:

- Land disturbances
- Spills and discharges
- Gas migration/leakages
- Pipelines






Conductivity and Total Dissolved Solids

- Conductivity measures the ability of water to pass an electrical current
- Total Dissolved Solids (TDS) measures the amount of ions dissolved in the water

(PA standard - 500 mg/L)

Voltage is applied between two probes to measure conductivity in microSiemens/centimeter (µS/cm)



TDS value (mg/L)

Why Conductivity and TDS?

- Frack water mixes with natural brine, found in the shale
- Flowback water contains higher concentrations of salts and metals



Meter Trials



Dickinson students, faculty, and staff helped test conductivity/TDS meters to determine which meter is most accurate, precise, and easy to use.


Meter A: LaMotte Tr	acer PockeTes	ter			
lesults	Solution A		Solution B		Solution C
Conductivity					
TDS					
id the reading stabi	lize? YES	NO			
low difficult was it to [1 = very diffi		meter? lt;3 = medium 4	= easy; 5 = very	easy]	
			4	5	
low difficult was it to	understand th				
low difficult was it to [1 = very diffi	understand thicult; 2 = difficu	he directions? It; 3 = medium 4	= e asy; 5 = very	easy]	
low difficult was it to [1 = very diffi 1	o understand ti icult; 2 = difficu 2	he directions? It; 3 = medium 4	= e asy; 5 = very	easy]	
low difficult was it to [1 = very difficult 1 Meter B: Oakton Mu	o understand ti icult; 2 = difficu 2	he directions? It; 3 = medium 4	= e asy; 5 = very	easy]	Solution C
low difficult was it to [1 = very difficult 1 Meter B: Oakton Mu	o understand ti cult; 2 = difficu 2 2 liti-Parameter Solution &	he directions? It; 3 = medium 4	= easy; 5 = very	easy]	Salution C
low difficult was it to [1 = very diffi 1 Meter B: Oakton Mulesults	o understand ti cult; 2 = difficu 2 2 liti-Parameter Solution &	he directions? It; 3 = medium 4	= easy; 5 = very	easy]	Solution C

Conductivity/Total Dissolved Solids Meter Testing

Thank you for participating in this meter testing session sponsored by the Alliance for Aquatic Resource

Barium and Strontium


- Naturallyoccurring metals found deep underground
- Indicate
 contamination
 from shale gas
 activities
 (signature
 chemicals)



Stage Monitoring







Visual Observations

- Earth Disturbances
- Gas Migration/Leakages
- Spills and Discharges
 Pipelines



Monitoring Locations & Well Permits



Step 1:

Find where drilling permits have been issued, or identify priority streams or existing pollution issues:

- PADEP map/reports
- PADEP eNotice
- FracTracker




Step 2:

Find coordinates and choose monitoring site based on important features:

- Well locations
- Stream access
- Availability


Data Use: Decision Trees

Chemical
Monitoring
*
Visual
Observations
*
Pipelines



Report
monitoring
information
when values
exceed criteria
in decision
trees

Online Database and Toolkit



30

Building a Monitoring Constituency

- Movement 2000 people trained since the start of 2010
- ALLARM, DRN, PACTU, PASA, MWA, Sierra Club, Waterdogs





Questions?

```
Alliance for Aquatic Resource Monitoring (ALLARM)

Dickinson College

P.O. Box 1773

Carlisle, PA 17013

717.245.1565

allarm@dickinson.edu

dickinson.edu/allarm

ALLARMwater.org
```

Monitoring Locations & Well Permits



Identifying Monitoring Locations

We will be discussing:

- Tools for finding and tracking wells
- Considerations for monitoring sites
- Volunteer roles for the group



Determine Monitoring Locations



Step 1:

Find where drilling permits have been issued, or identify priority streams or existing pollution issues.

- PADEP map/reports
- PADEP eNotice
- FracTracker



Step 2:

Use reports and coordinates to choose monitoring site based on important features

- Well locations
- Stream access
- Availability

PA Oil and Gas Mapping


http://www.depgis.state.pa.us/PaOilAndGasMapping

Pros:

- Most current information
- Many options for searching (can search by well status, operator, permit number)

Cons:

- Somewhat clunky interface (but does have help page with definitions and guides)
- May have limited browser support



FracTracker


https://www.fractracker.org/map/us/pennsylvania/pa-shale-viewer/

Pros:

- Wider browser support
- Easier to use

Cons:

 Not always the most up-to-date information



http://www.depweb.state.pa.us





DEP > Data and Tools > Reports

REPORTS

In an effort to maximize transparency and improve efficiency, DEP provides easy access to dozens of online reports and key data about the many programs the agency administers.



Oil and Gas Mapping

INTERACTIVE REPORTS

Interactive Reports Data Dictionary

Permits Issued Detail Report

Monthly - Permits Issued by County and Well Type Report

Year to Date - Permits Issued by County and Well Type Report

Oil and Gas Operator Well Inventory

Oil and Gas Compliance Report

SPUD Data Report

Wells Drilled By County

Wells Drilled By Operator


Oil and Gas Production Reports

Oil and Gas Well Production Status

Oil and Gas Electronic Notifications

DEP Orphan and Abandoned Wells





Contains information about oil & gas wells:

- Permits issued (by operator and county, updated weekly)
- Active well inventory (by county)
- Spud reports/date drilling begins (updated weekly)

DEP's Active Well Inventory: All of the active oil & gas wells in Washington County

COUNTY	MUNICIPALITY	PERMIT ISSUED DATE	OPERATOR	APPLICATION TYPE	WELL API	UNCONVENTINONAL	HORIZONTAL WELL	WELL TYPE	LATITUDE DECIMAL	LONGITUDE DECIMAL
Washington	Buffalo Twp	6/27/2012	RANGE RESOURCES APPALACHIA LLC	NEW	125-24793-00- 00	Yes	Yes	GAS	40.169305	-80.350775
Washington	Hanover Twp	6/13/2012	RANGE RESOURCES APPALACHIA LLC	NEW	125-24787-00- 00	Yes	Yes	GAS	40.421611	-80.511644
Washington	Hanover Twp	6/13/2012	RANGE RESOURCES APPALACHIA LLC	NEW	125-24788-00- 00	Yes	Yes	GAS	40.42163	-80.511538
Washington	Independence Twp	6/26/2012	RANGE RESOURCES APPALACHIA LLC	NEW	125-24692-00- 00	Yes	Yes	GAS	40.226336	-80.445855
Washington	Independence Twp	6/26/2012	RANGE RESOURCES APPALACHIA LLC	NEW	125-24692-00- 01	Yes	Yes	GAS	40.226336	-80.445855
Washington	Independence Twp	6/26/2012	RANGE RESOURCES APPALACHIA LLC	NEW	125-24693-00- 00	Yes	Yes	GAS	40.226369	-80.445952
Washington	Independence Twp	6/26/2012	RANGE RESOURCES APPALACHIA LLC	NEW	125-24693-00- 01	Yes	Yes	GAS	40.226369	-80.445952

eNOTICE

- DEP's Electronic Notification system
- Receive information and track changes to oil & gas permits
- http://www.ahs2.dep.state.pa.us/eNOTICEWeb/



```
eNOTICE - Changes to Tracked Permits Inbox X
ra-epenotice@state.pa.us to me
                                                                 show details 10:00 AM
 The following Permit Applications have changed as of Friday, June 04, 2010.
 Bradford County:
    Authorization # 832571 has been updated on 6/2/2010.
      Subfacility ID=1012995 Name=COATES 5H eMapPA search
    Authorization # 835515 has been updated on 6/2/2010.
       Subfacility ID=1014502 Name=RICH 2H eMapPA search
    Authorization # 835521 has been updated on 6/2/2010.
       Subfacility ID=1014514 Name=HAYWARD 5H eMapPA search
    Authorization # 835608 has been updated on 6/2/2010.
      Subfacility ID=1014543 Name=OSHEA 2H eMapPA search
    Authorization # 835618 has been updated on 6/2/2010.
      Subfacility ID=1014549 Name=MATT WILL FARMS 2H eMapPA search
    Authorization # 836423 has been updated on 6/2/2010.
      Subfacility ID=1012995 Name=COATES 5H eMapPA search
    Authorization # 836429 has been updated on 6/2/2010.
       Subfacility ID=1014871 Name=FEUSNER 03 045 01 J 1H eMapPA search
    Authorization # 836433 has been updated on 6/2/2010.
      Subfacility ID=1014872 Name=FEUSNER 03 045 02 J 2H eMapPA search
    Authorization # 836435 has been updated on 6/2/2010.
      Subfacility ID=1014873 Name=YURKANIN 03 014 01 J 1H eMapPA search
    Authorization # 836444 has been updated on 6/2/2010.
       Subfacility ID=1014874 Name=YURKANIN 03 014 02 J 2H eMapPA search
    Authorization # 836449 has been updated on 6/2/2010.
       Subfacility ID=1014877 Name=YURKANIN 03 014 03 J 3H eMapPA search
    Authorization # 836452 has been updated on 6/2/2010.
       Subfacility ID=1014878 Name=YURKANIN 03 014 04 J 4H eMapPA search
    Authorization # 836454 has been updated on 6/2/2010.
      Subfacility ID=1014883 Name=YURKANIN 03 014 05 J 5H eMapPA search
    Authorization # 836470 has been updated on 6/2/2010.
       Subfacility ID=1014885 Name=YURKANIN 03 014 06 J 6H eMapPA search
    Authorization # 836477 has been updated on 6/2/2010.
      Subfacility ID=1014889 Name=YURKANIN 03 014 07 J 7H eMapPA search
    Authorization # 836478 has been updated on 6/2/2010.
```

Group Roles – Checking Permits

- It may be effective to designate one person to check for new permits in the area
 - Can be someone who is already checking permits, or someone interested in permitting information, and report information to the group



Safety Considerations



http://farm3.static.flickr.com/2405/1516087369_fb0226bc11.jpg

General advice

Develop language as a group that describes what you are doing...

"Monitoring stream health" vs. "Tracking down fracking polluters"



http://www.alicia-logic.com/email/ Close%20Encounter%20with%20a%20Pit%20bull.jpg

Property Access

- Public land, such as State Game Lands or state forests, are open to the public
 - Access rights are not a concern
 - However, you are not allowed on active drilling sites due to safety concerns (industrial site)
- For private properties, always ask the landowner's permission



http://unitednuclear.com/images/sign3.jpg

Personal Safety

- Do not make contact with water or soil that could be contaminated unless you have protective clothing
 - Wading boots
 - Latex gloves

Do not put yourself into a situation that may be

dangerous.




Personal Safety

- When out in the field, bring a cell phone and leave it on
- Steer clear of confrontation. Leave the area if someone confronts or threatens you.




http://www.jaimesmcneal.com/Jaimes_McNeal/Blog/Entries/2009/12/21_Conflict,_it%E2%80%99s_not_just_for_breakfast_anymore! files/shapeimage 2.png

Physical Parameters



Protocol developed alongside:

- Bradford County
 Conservation District
- Mountain Watershed Association
- PA Trout Unlimited
- Pine Creek Waterdogs
- EarthJustice




Visual Observations

- Document physical status of the stream
- Identify potential impacts/pollution events
- Report violations and/or suspicious activity



Recording Observations: Data Sheet

June 2016



Alliance for Aquatic Resource Monitoring (ALLARM)

Record latitude and longitude or Site ID/ location description

Take photograph (date and time stamp) and record on the data sheet


Record thorough description of the observation

Recording Observations: Field Data Log


Record Site ID or latitude and longitude

Record multiple times or locations

Record visual observation description and outcomes



Recording Observations: ALLARMwater.org



Visual Observation Categories


- Earth Disturbances
- Gas Migration/Leakages
- Spills and Discharges
- Pipelines



Pipelines




Types of Pipelines



- Gathering Lines: Small lines from wells.
- Transmission Lines: Larger lines that transport gas long distances, compressor stations every 40-60 mi to keep gas at a high enough pressure for travel.
- **Distribution Lines**: Small lines going into homes, businesses etc.

Major Pipelines



Environmental Concerns

- Erosion and sedimentation (largest concern, most common violation)
- Loss of riparian zones vegetated buffer along the stream

Stream geomorphology impacts (changes in

stream shape)

- Habitat fragmentation
- Methane leakages



Stream Crossings

Through the stream








Through the Stream

- Open-cut
- Flumed or Partial Diversion
- Dam & Pump method










Under the Stream

Horizontal Directional Drilling










(Direct Industry, 2014)





Earth Disturbances



Earth Disturbances

 Sediment entering streams as a result of any earth disturbance Sediment on/from access roads, well pads.





What do you notice?





Access Roads





What do you notice with these access roads?

Main Roads





Best Management Practices for E&S

Silt fence



Silt Sock



Diversion Ditch



Monitoring erosion and sedimentation best management practices (E&S BMPs): need to confirm that they are installed correctly and maintained properly.

Sediment from Earth Disturbances





Is there a problem with these best management practices?

E&S Best Management Practices

Is there anything wrong with this?



PA: Publicly available information



E&S plans are on site & are available to the public.

Pipeline Erosion & Sedimentation





Tioga County, PA - Mudslides





Tioga County Conservation District

Spills and Discharges



Spills and Discharges


Unusual odor, color, foam and/or bubbles

Dead fish and/or other organisms





Spills and Discharges



Pipeline Spills and Discharges Bentonite Blowouts







Illegal Dumping into Streams

- No pump running
- Bubbling at end of hose
- Unusual odors
- Discoloration of water near hose



Illegal Dumping





Which is illegal dumping?



Gas Migration or Leakages









What do you see?



Data Management: Record Results


ſ	Site ID or Stream Location Descrip			Latitude (if no Site ID): Longitude (if no Site ID):			ALLARM Volunteer Monitor Field Log Monitor's Name:				
	Chemical and St	tage Results					Total Control of the				
	Date (MM/DD/YY)	Time when you monitored	Conductivity (µ5/cm) replicate 1	conductivity (µS/cm) replicate 2	Average Conductivity	TDS (mg/l) replicate 1	TDS (mg/i) replicate 2	Average TDS	Stage (ft)	Calibrate (Yes/No)	Time spent monitoring (minutes)
				-							
ľ	-										
Ī			-								
Ī											
Ī	-										
Ī						-				_	
Ì	Weether and Precipitation Observations			Visual Observ	atons Results						
	Weather (sunny, partly cloudy, or cloudy)	Precipitation (none, light rain, heavy rain, or snow)	Precipitation Last 48 Hours (none, light, or heavy)	Notable or reportable observations (refer to visual observation checklist)?		Violation Reported (Yes/No)	Violation Reported To:		ed To:	Picture Taken? (Yes/No)	Pipeline Disturbance (Yes/No)
ı											
ſ											
1											
Ī											
1											






ALLARMwater.org


Reporting Observations





It is important to communicate with your local agencies — "hey, we're here and we're monitoring."

Pipeline Decision Tree



Chemical Parameters





Alliance for Aquatic Resource Monitoring

Objectives

- Learn about water quality parameters.
- Build basic skills for monitoring.
- Learn about quality assurance/quality control.





Indicators

Water Quality:

- Conductivity
- Total Dissolved Solids (TDS)

Water Quantity:

Stage (water depth)



Meter Trials



Dickinson students, faculty, and staff helped test conductivity/TDS meters to determine which meter is most accurate, precise, and easy to use.

Additional questions	are tound on pa	ge 2 – please pr	ovide as much	feedback as p	ossible!
Meter A: LaMotte T	racer PockeTest	er			
Results	Solution A		Solution B		Solution C
Conductivity					
TDS					
Did the reading stab	ilize? YES	NO			
How difficult was it t [1 = very diff	o calibrate the n icult; 2 = difficult		= e as y; 5 = ven	y easy]	
1	2	3	4	5	
How difficult was it t [1 = very diff	o understand the icult; 2 = difficult		= e asy; 5 = ven	y easy]	
1	2	3	4	5	
Meter B: Oakton Mo	ulti-Parameter P	CSTestr 35			
Results	Solution A		Solution B		Solution C
Conductivity					
TDS					
Did the reading stab	ilize? YES	NO			
How difficult was it t	o calibrate the m		= e stv: 5 = ven	v essyl	

Conductivity/Total Dissolved Solids Meter Testing

Thank you for participating in this meter testing session sponsored by the Alliance for Aquatic Resource Monitoring (ALLARM). Please answer the questions on page 1 about each water quality meter.

Calibration

- Calibrate every day you monitor
- Dispose of calibration fluid after use





Conductivity (μ S/cm)

- Conductivity measures the ability of water to carry an electrical current/presence of ions:
 - Inorganic compounds = good conductors
 - Example: dissolved salts and heavy metals
 - Organic compounds = poor conductors
 - Example: pesticides
- Conductivity is measured with a meter. Voltage is applied between two electrodes in a probe immersed in water.

Ranges

Distilled Water: $0.5 - 3 \mu S/cm$

US Streams: $15 - 500 \,\mu\text{S/cm}$

US Rivers: $50 - 1500 \,\mu\text{S/cm}$

Industrial Waters: up to 10,000 μ S/cm



Total Dissolved Solids (mg/L)

TDS measures the amount of ions in the water.

• Example: dissolved salts, nutrients, heavy metals

- Meters first measure conductivity and calculate TDS using an equation.
- TDS can be measured directly using the gravimetric method (actual weight).

Ranges

Fresh Water: < 1,500 mg/L

Brackish Water: 1,500 - 5,000 mg/L

Saline Water: > 5,000 mg/L



Why Conductivity and TDS?


- Frack water mixes with natural brine, found in the shale
- Flowback water contains high concentrations of salts and metals




Stage Monitoring (ft)








Conductivity and Stage Relationship



Flowback Water Concentrations



Source: Amy Bergdale, USEPA

Reportable Event

A conductivity level 3x or higher than a measurement at a comparable stage.

Date	Stage	Conductivity
2/6/2016	1.7	119.3
2/15/2016	1.7	132.3
3/7/2016	0.8	361
3/13/2016	1.7	670

Reporting Events

Reportable Event Steps:

- 1. Re-calibrate meter and re-test your water.
- 2. Collect a sample for barium & strontium analysis (to send to a local, certified lab).
- 3. Contact your local group leaders.
- 4. Contact enforcement agencies.
- 5. Contact ALLARM.


Barium & Strontium: Signature Chemicals

- If Conductivity/TDS levels increase, that could mean pollution from shale gas flowback water.
- Data are confirmed by analyzing samples for Ba & Sr



It is important to obtain baseline data for conductivity/TDS and barium/strontium. It is also important to understand how they relate under different flow conditions.

Reporting Events




CONTACT:

- . PA DEP Regional Office
- PA Fish and Boat Commission
- ALLARM
- EPA Region 3 Tipline
- County Conservation District
- Local Community/ Environmental Group
- · Facility Owner/Operator

Baseline Monitoring Steps



2. Conductivity & Total Dissolved Solids In-stream testing





Visual
 Observation
 Checklist



3. Stage Monitoring

Stream Testing

- Test stream water with meter
 - Walk into middle of the creek
 - Or sample from a bridge using a bucket





Creekside vs. Home testing

Mandatory Creekside Testing

- Stage
- Visual observations

Can do at home in bad weather

- Calibration
- Conductivity/TDS

Meter does not stabilize quickly in freezing temperatures, turn the meter on when you arrive at the site or let the water warm to room temperature test at home or in the car.



Recording Results

ALLARM				Chemic	ai anu	orage IV	CHILOI	ing Date	a sneet		
es/. 198b											
1. Record yo Site Inform		nd samp	le infor	mation in t	he boxes		Informa	tion			
Stream Nar	ne					Monito	r's Name				
Site Locatio	in					Collection	on Date				
Latitude Co	ordinate					Collection	Collection Time				
Longitude (Coordinat	e				County Monitored		ed			
2 Chack the	daccrinti	on that	bart m	atches vou	r obcorn	ation:					
Weather	· oescripti	on that	Descri	atches your observation: Precipitation				Precipit	ation Las	t 48 Hours	,
Sunny				Light rain				None			
Partly Cloud	dy			Heavy rai	n			Light			
Cloudy				Snow				Heavy			
3. Record yo	our result	s in the	boxes b	elow:	-						
Parameter			nits	Repl	icate #1		Replic	ate #2		Average R	esult
Conductivit	y .	μS	/cm								
Total Dissol	lved Solid	s m	ng/L								
Stage		f	eet								
inches to fee	et convers	ion:									
Inches	1	2	3	4	5	6	7	8	9	10	1
Feet	0.08	0.17	0.25	0.33	0.42	0.50	0.58	0.67	0.75	0.83	0.5

Record site information

Record weather information

Record conductivity, TDS, and stage results

Record calibration and volunteer time.


Alliance for Aquatic Resource Monitoring (ALLARM)

Inne 201

Data Management & Quality Control


ALLARMwater.org

- 'My Data' profile page
- Submit data through site
- Can view data and create graphs
- Resources, research and forms all housed on site




Data Management: ALLARM water.org

- Submit data through site
- Checks values and tests for reportable events



Data Management: ALLARMwater.org

- Can create data and create graphs
- Resources, research and forms all housed on site




Quality Control Program

- Ensures the credibility of the data collected.
- ALLARM will test the water using the same equipment as well as other methods.
- Compare monitor's results to ALLARM's results.

	Conductivity (LaMotte)		TDS (LaMotte)	TDS (Accumet)
Monitor	X		X	
ALLARM	X	X	X	Χ

Quality Assurance, Quality Control (QA/QC)

- Fill out QA/QC form
- Collect sample
- Send form and sample to ALLARM lab
- Do twice a year high stage & low stage



Quality Control

Appendix E: Quality Assurance/Quality Control Form



SHALE GAS VOLUNTEER MONITORING PROGRAM Quality Assurance/Quality Control (QA/QC) Form

- 1. Fill out the label on your QA/QC bottle (shown to the right).
- 2. Enter the stream and face upstream, Fill your QA/QC bottle and pour the rinse water out downstream. Rinse your bottle and cap three times. Fill your QA/QC bottle completely with stream water and close it tightly with the cap.
- 3. Record your data in the chart below, as well as on ALLARMwater.org:



Parameter	Units	Replicate #1	Replicate #2	Average Result
Conductivity	μS/cm			
Total Dissolved Solids	mg/L			
Stage	feet			

4. Fill out the information in the boxes below:

Monitor Information	Sample Information				
Monitor's Name	Site ID or Stream Name				
	Latitude Coordinate				
Mailing Address	Longitude Coordinate				
Email Address	Collection Date	- 0			
County Monitored	Collection Time				
Affiliation	Equipment Used (i.e. LaMotte meter)				
(if applicable)	Bottle # (on label):				

5. Pack a small box with your QA/QC bottle and this QA/QC form. Secure the bottle so it cannot move around during shipment. Mail the box to ALLARM for QA/QC processing at:

Dickinson College

5 N Orange Street Carlisle, PA 17013

- Send water sample to ALLARM within first month of monitoring for QA/QC and barium/strontium analysis.
- Be sure to log observations for QA/QC samples on **ALLARMwater.org**

In your kit

- LaMotte Tracer
 PockeTester and calibration solution vial
- 2. 84 μS/cm & 1413 μS/cm standard calibration solution
- 3. Distilled water wash bottle
- 4. Stream testing bottle
- 5. 3 sample bottles
 - Two sample bottles for QA/QC
 - One bottle for pollution event Ba and Sr analysis
- 6. Gage Stick

