

VCR TO DVD

Turn the JVC player, and the TV on



Insert a blank DVD and the tape in the JVC Player



Use the AUX button on the remote until you see the tape show on the TV. The TV needs to be on AV1 Mode.



Play the tape until you find the beginning of your recording. Pause.



Click on the Dubbing button on the JVC.

This screen will show on the TV. Select Dubbing



Recording will start.

If you want to finish the recording before the end of the tape, press STOP on the JVC Player



It is very important to Finalize the DVD when you are done so it can be played on other players as well



The JVC Player has to be on DVD mode. If it is not, click on the DVD/VCR Button



Click HOME on the Remote

Find Easy Menu on the screen navigating with the arrows on the Remote. Select Disk Manager and click Enter on the remote.

A screen like this
will appear....



Select Finalize

Enjoy your DVD.